

## Troubleshooting Tips

Fault	Remedy
Liquid escapes out below the filling plate/device is leaky	Replace the sealing ring (Service set item no. 0891 870 100), test again with different cans
Sealing ring wears in a very short time	Check the valve at the can bottom! Sharp-edged burr formation can damage the O-ring. Have third-party materials been used for filling?
Can cannot be filled	Vent the can before each filling. Material does not flow with residual pressure still in the cans. Check whether there is still material in the drum or canister. Check that no hoses are kinked/defective. Is the coding correct? Brake cleaner cans can only be filled with the brake cleaner station. Has a REFILLO can been used inadvertently? Is the compressed air connected?
After connection of a new canister/drum, the cans are no longer filled	Repeat the filling process several times until the cylinder is full with material again. Vent the can each time
Filling processes is no longer triggered	Check the 3-way valve! Use maintenance spray and activate the release pin several times from above. The noise must be audible! Check the compressed air supply
Can is not suitable for the station	Observe the coding! Compare the engraved numbers of the can bottom and the filling plate
Can leaks	Procure a replacement can
The pressure in the can is too low	Add compressed air via the compressed air nipple